

Installation Guide: Park-It Parking Stop

Components:


- Park-It parking stops
- ½" (diameter), 14" (length) rebar spikes for asphalt or lag bolts with washers and metal shields for concrete – available at SafestParkingProducts.com

What You Need:


- Gloves, safety glasses
- Traffic cones, drums or barricades for securing the site
- Mallet
- Heavy duty electric drill
- ½" masonry bit and, if installed with the lag bolts: a masonry bit required for the metal shields – consult bit size on side of shield
- A drive socket and a power tool for installation of the lag bolts


The flexible design of the Park-It car stop allows the product to conform to the contour of uneven road surfaces and can be installed on both asphalt and concrete.

Installation Instructions for Asphalt: Installation of Park-It car stops with Spikes

STEP 1:	Drill ½" diameter holes (3 – 4" in depth) in the asphalt through the product's holes.	
STEP 2:	Drive ½" rebar spike (14" long) through the holes in the product.	

Installation Instructions for Concrete: Installation of Park-It car stops with lag bolts and metal shields

STEP 1:	Use ½" or 5/8 lag bolts (6" long).	
----------------	------------------------------------	---

STEP 2:	Drill ½” diameter pilot holes, (3 – 4” in depth) through the product’s installation holes.	
STEP 3:	Remove the product; re-drill the holes for the diameter and depth required by the metal shields.	
STEP 4:	Install the metal shields, re-position product and bolt with lag bolts / washers.	